



**ROADSMITH**  
TRIKE CONVERSIONS BY  
**THE TRIKE SHOP**



Please thoroughly review the instructions before and during installation. Keep in mind that this product was designed to be installed by trained dealer technicians. If you are a do-it-yourselfer, be patient, trust your common sense, and if necessary call your dealer or contact The Trike Shop at 800-331-0705 if you run into any problems you cannot solve.

---

APPLICATION: Roadsmith HDT trike

PRODUCT: Mudflaps

VERSION: 1

GENERAL NOTES: Please note location of all parts. Refer to pictures.

---

The pictures show the installation without the body in place. The mudflaps may be installed before or after the body installation.

1. Install the mud flaps onto the left and right brackets
  - a. For mudflaps with lights, route the wiring between the mudflap and the bracket
  - b. Do not over-tighten the fasteners
2. Install the brackets to the chassis
3. For mudflaps with lights
  - a. Remove the taillight lens to plug in the extension harness
  - b. Zip tie all wiring to prevent contact with tires, exhaust, etc
  - c. Reinstall taillight lens

