
APPLICATION: Roadsmith HT1500 trike conversion
PRODUCT: BHU mud flap and bracket installation
VERSION: #2
GENERAL NOTES: Please don't attempt any shortcuts.

1. Install the mud flaps on to the brackets (Pic #1)
 - a. If installing lighted flaps, refer to diagrams provided with them for wire routing and securing.
 - b. Install them so that the plug from the light is oriented toward the inside of the trike
 - c. Install the flaps on the rear side of the brackets
2. Remove and discard the two forward body mounting bolts from inside the trunk (Pic #2)
 - a. Save the washers and spacers
 - b. Replace these bolts with the provided 5/16" x 2-1/4" bolts
3. Install the brackets with flaps onto the body mount tubes as shown using the provided hardware (Pic #3)





